

Tired of the dirt and grime on your C-5 tail lights?

Here is how to mount tail lights flush with bumper and to install seal around lights to keep dirt out.



Items Needed: (All from Lowes at a total cost of \$8.45)

- a. 1 pkg MD Sponge Window Seal from Lowes 3/8" H x 1/2" W x 10' L (\$3.60)
- b. Spacers – cut from 1/4 inch (ID) semi-flexible tubing (5' tube cost \$2.49)
 - 6 @ 1" Use two on both center lights and one on inside slot of outside lights.
 - 2 @ 3/4" Use one on each of the outside slots of the outside lights
- c. Screws – 8 size #8 x 2 1/2" pan head screws (same as sheet metal) (\$2.36)

Remove tail light. Remove bulb housing. Clean lens and remove dirt from tail light housing.

Start in the center of the bottom of the lens, place seal along the back edge of the red lens where it joins the black housing. Joint should be at bottom of lens.

Insert screws and place spacer over screws. Screws are long enough to be able to see behind the lens to locate the screw holes. Insert each screw in the screw hole and tighten only several turns leaving the lens loose. Carefully push the lens into the bumper tail light slot making sure that the seal is equal all the way around the lens. When the lens and seal appear to be seated properly, slowly tighten the screws. You can check to see that the lens is seated all the way against the spacers by pushing on the lens to see if the screw head shows gap between it and the lens. If so, carefully tighten more making sure that the seal is still equal all the way around.

If you have any questions or need assistance, call me at 591-4141.

Ken Rouse